



MOUNTING INSTRUCTIONS, MIRROR SUPPORTS

All Mirror supports should be attached at four (4) points: A,B,C,D.

- Point A. Top of rod and top of mirror frame. Attach support to mirror with wood screw through hole at top of rod.
- Point B. Bottom of mirror frame. If three (3) brackets are furnished, attach bracket here; if not, attach support with wood screws through slot.
- Point C. Top Plate of dresser. If brackets are furnished, attach bracket here; if not, attach support here with wood screw through slot.
- Point D. Drawer support frame. Locate and mark location of drawer support frame. If brackets are furnished, locate last bracket here. If not, attach support here with wood screw.

Adjust mirror height to suit, then tighten all brackets and screws.